




- NOTES:
1. REMOVE ANY DAMAGED OR LOOSE EXISTING CIM.
 2. PREPARE THE SUBSTRATE IN ACCORDANCE TO CIM INDUSTRIES'S INSTRUCTION GUIDES.
 3. ABRASE 6"-12" OF EXISTING CIM AND SOLVENT WIPE CLEAN (XYLENE OR MEK) PRIOR TO APPLICATION OF CIM BONDING AGENT.
 4. ALLOW THE CIM VOC COMPLIANT BONDING AGENT TO FLASH OFF AND RECOAT WITH THE CIM REPAIR MATERIAL WITHIN (1) HOUR.
 5. (OPTIONAL/NOT SHOWN) PRIME CONCRETE WITH CIM ECO OR CIM EMT EPOXY PRIMER.

  	
TITLE	
REPAIR DETAIL	
SIZE	DWG NO CIM-CWMR1
SCALE NONE	REV
SHEET 1 OF 1	