



NOTE: 1. No protective board is required for Royston 108 ARN
 2. Install Gasket as per Manufacturer recommendations
 3. Refer to "Royston® Waterproofing Membrane Installation Guidelines" and Technical Data Sheet for instructions

CREATION DATE 08/02/2022	 		
CHECKED DATE 08/02/2022	TITLE BOX CULVERT JOINT WATERPROOFING DETAIL		
DRAWN MCCALL	SIZE B	DWG NO RM-7	REV
SCALE NONE	SHEET 1 OF 1		