


NOTES

1. Make the top of the expansion joint material from 1/8" to 1/4" below the surface, unless otherwise indicated or directed.
2. Eva-Pox Bondor #1 applied to both substrate surfaces and filling the grooves on the joint material.
3. Refer to CEVA Expansion Joint System Guide and Technical Data Sheets for instructions.
4. Make the joint material 25% (Typ.) wider than the joint opening measured at 68°F (20°C)

CREATION DATE 04/05/2023			
CHECKED DATE 04/05/2023	TITLE		
DRAWN MCCALL	CEVA EXPANSION JOINT SYSTEM WITH STEEL ANGLES		
	SIZE B	DWG NO EXJ-5	REV
	SCALE NONE	SHEET 1 OF 1	